

Ultra Seismic Rentals Ltd. Helibag Assembly Instructions



Ultra Seismic Rentals Ltd. Calgary Alberta Canada (403) 816-2827

Thank you for your recent helibag purchase. Our product was designed to work with the Mr. T's Universal picker. They may or may not work with other pin/cone set-ups. Please inspect the bags and lanyards for wear on a regular basis. Failure to do so can result in personal injury, equipment damage or loss. Ultra Seismic Rentals Ltd. is not responsible for wear or breakage to the bags or lanyards.

To save on trucking space your bags are delivered unassembled. Please use the following instructions to assemble the equipment in the correct manner for best long-term utilization.



The components included are:

1. Flight Bag
2. Lanyard
3. Aluminum Pin
4. Plastic Set-up Cone
5. Quick Link Closure
6. Pear Ring

Assemble the unit in the following order:

1. Open up the flight bag.
2. Pull one end of the lanyard through the aluminum pin.
3. Pull the aluminum pin to the middle of the lanyard.
4. Take the looped ends of the lanyard and drop them both through the hole in the top of the cone.
5. Pull each side of the lanyard through 4 of the "D" rings on the flight bag.
6. The quick-link closure is installed with both ends of the lanyard on the threaded end of the link.
7. Before closing the quick-link gate insert the pear ring.
8. Close the quick-link gate tightly. Tools may be required.



Diagram above shows the lanyard through the aluminum pin and the looped ends of the lanyard dropped through the hole in the top of the cone.



Diagram above shows a correctly assembled helibag.

When using a carrousel instead of the Mr. T's Universal picker (bagging on to a program for instance) use the pear ring on the carrousel gate not the rope lanyard. This will hold the cone from flapping during flight and save wear on the lanyard, thus protecting you and your equipment.